

A new General Purpose Decontamination System for Chemical and Biological Warfare and Terrorism agents

**Sushil Khetan, Deboshri Banerjee, Arani Chanda,
and Terry Collins**


Institute for Green Oxidation Chemistry
Carnegie Mellon University, Pittsburgh, PA 15213

Joint Services Scientific Conference on Chemical & Biological Defense Research

November 20, 2003

Report Documentation Page				Form Approved OMB No. 0704-0188	
Public reporting burden for the collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden, to Washington Headquarters Services, Directorate for Information Operations and Reports, 1215 Jefferson Davis Highway, Suite 1204, Arlington VA 22202-4302. Respondents should be aware that notwithstanding any other provision of law, no person shall be subject to a penalty for failing to comply with a collection of information if it does not display a currently valid OMB control number.					
1. REPORT DATE 19 NOV 2003		2. REPORT TYPE N/A		3. DATES COVERED -	
4. TITLE AND SUBTITLE A new General Purpose Decontamination System for Chemical and Biological Warfare and Terrorism agents				5a. CONTRACT NUMBER	
				5b. GRANT NUMBER	
				5c. PROGRAM ELEMENT NUMBER	
6. AUTHOR(S)				5d. PROJECT NUMBER	
				5e. TASK NUMBER	
				5f. WORK UNIT NUMBER	
7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES) Institute for Green Oxidation Chemistry Carnegie Mellon University, Pittsburgh, PA 15213				8. PERFORMING ORGANIZATION REPORT NUMBER	
9. SPONSORING/MONITORING AGENCY NAME(S) AND ADDRESS(ES)				10. SPONSOR/MONITOR'S ACRONYM(S)	
				11. SPONSOR/MONITOR'S REPORT NUMBER(S)	
12. DISTRIBUTION/AVAILABILITY STATEMENT Approved for public release, distribution unlimited					
13. SUPPLEMENTARY NOTES See also ADM001851, Proceedings of the 2003 Joint Service Scientific Conference on Chemical & Biological Defense Research, 17-20 November 2003. , The original document contains color images.					
14. ABSTRACT					
15. SUBJECT TERMS					
16. SECURITY CLASSIFICATION OF:			17. LIMITATION OF ABSTRACT UU	18. NUMBER OF PAGES 32	19a. NAME OF RESPONSIBLE PERSON
a. REPORT unclassified	b. ABSTRACT unclassified	c. THIS PAGE unclassified			

Fe-TAML[®] Activator of Peroxide



TAML[®] Activators developed
at Carnegie Mellon University

New Applications

Rapid Inactivation of Bacterial Spores and degradation of organophosphorus triesters as surrogates of Biological and chemical Warfare Agents

'Green' Oxidizing System¹

- Biomimetic System
- Non-toxic and non-corrosive
- Efficient user of peroxide
- High turnover in oxidative environment

Tested Applications^{1,2}

- Effluent Treatment
- Bleaching in Pulp and Paper
- Desulfurization of Diesel
- Dye Transfer Inhibition Agent

1. Collins, T. J. *Accounts of Chemical Research* **2002**, 35, 782-790
2. [http:// www.cmu.edu/Greenchemistry](http://www.cmu.edu/Greenchemistry)


Activators of Hydrogen peroxide

Relative Rates of Reactive Intermediates Formation

- Bicarbonate Activated Peroxide* System
(Aqueous Foam decon by Sandia National Laboratory)



- Fe-TAML[®] activators of hydrogen peroxide



- Deep Oxidation capability
- Non-toxic and non-corrosive

$$k'/k = 10^7$$

* Richardson, D. E. *et al. J. Am. Chem. Soc.* **2000**, 122, 1729



Biological Warfare Agents

A microorganism or its by-product (toxin), which causes disease in man, plants or deterioration in material; used as weapons of warfare and/or terrorism

Major Threats


- Bacterial Diseases
 - Anthrax
 - Tularemia
 - Plague
- Viral Diseases
 - Smallpox
 - Viral hemorrhagic fevers
- Toxins
 - Botulinum Toxins
 - Ricin

Anthrax Spores




- Dormant survival form of the vegetative bacterium
- Resistant to stress conditions, e.g. heat, UV radiations and chemical treatments
- Germinates on encountering favorable conditions

Bacterial Endospore



Source: L. M. Prescott,
Microbiology, McGraw-Hill,
NY, 5th Ed., 2002



Spore resistance is due to two protective shells that encase the organism

Spore Coat

Multi-layered highly cross-linked polypeptide structure with numerous disulfide linkages

Spore Cortex

Thick layer of loosely cross-linked peptidoglycan structure with an overall negative charge

Spore Core

- Normal cell structures with ribosomes and a nucleoid
- Metabolically inactive and largely dehydrated


Bacterial Spore Deactivation

Strategies and Mechanism

Strategies

- Penetration of the spore coat with subsequent degradation of bacterial DNA
- Dissolution of spore peptidoglycan structure, exposing the vegetative cell elements
- Initiation of germination with weakening of spore wall followed by deactivation
- Inactivation of spore germination apparatus by destruction of germination-specific lytic enzymes


Weakening of spore coat through oxidation of the disulfide bonds




Model compound:
Dialkyldisulfide (e.g. Cystine)

Modeling Studies

Oxidation of Di-alkyl Disulfides




Dissociation of disulfide bonds also observed in *di-tert*-butyl disulfide



Result obtained from ESI-MS studies

Deactivation Studies with *Bacillus* spores




Bacillus atrophaeus
(formerly *B. globigii*)

Spore-forming harmless soil bacterium *B. atrophaeus* (ATCC 9372) was tested as surrogate for *Bacillus anthracis* in spore deactivation studies

Optimization of Reaction Conditions

Variation of Fe-TAML[®] concentrations



N_0 = Initial number of spores


N = Number of surviving spores

- Studies conducted at two H_2O_2 concentrations
- Exponential relationship between spore deactivation and Fe-TAML[®] concentration
- Optimized Fe-TAML[®] concentration: 10 μM

- Reactions carried out for 1 hour at 30°C
- Spore Population of 5×10^7 CFU/ml
- Na-carbonate/bicarbonate (0.1 M) buffer, pH 10.0

Optimization of Reaction Conditions

Variation of H_2O_2 concentrations



N_0 = Initial number of spores

N = Number of surviving spores

- Linear relationship between spore deactivation and concentration of H_2O_2
- Optimized H_2O_2 concentration: 0.5M


- Reactions carried out for 1 hour at 30°C
- Spore Population of 5×10^7 CFU/ml
- Na-carbonate/bicarbonate (0.1 M) buffer, pH 10.0

Use of Cationic Surfactant

Cationic Surfactants

- Enhance penetrability of Fe-TAML[®] activators across the spore coat
- Increase dispersion of hydrophobic spores in aqueous phase
- Can cause collapse of spore peptidoglycan structure through ionic interactions


Optimized concentration: 0.03%
(close to cmc value)



N_0 = Initial number of spores


N = Number of surviving spores

Time Dependence of Spore Kill




10,000×


Control



10,000×


95% mortality
with hydrogen peroxide

10,000×


99.98% mortality
with Fe-TAML[®] activator,
and hydrogen peroxide N_0 = Initial number of spores N = Number of surviving spores

- 99.98% (4-log) kill of spores
- Treatment time: 2 hours
- Fe-TAML[®]: 10 μ M; H₂O₂: 0.5 M
- Spore population: 1×10^8 cfu/ml

Enhanced Spore Mortality



N_0 = Initial number of spores
 N = Number of surviving spores



75% with $t\text{BuOOH}$





99.99999%
 with Fe-TAML[®]
 + $t\text{BuOOH}$

- 99.99999% (7-log) kill of spores
- Treatment time: 1 hour
- Fe-TAML[®]: 5 μM ; $t\text{BuOOH}$: 0.3 M
- Spore population: 1×10^8 cfu/ml


Oxidative Detoxification of Organophosphorus Triesters and Dialkyl sulfides

TAML[®]-activated H₂O₂ Treatment of Fenitrothion




UV-Visible spectroscopic study

TAML[®]-activated H₂O₂ Treatment of Fenitrothion




Kinetics of decomposition of fenitrothion is followed through absorption at 396 nm In UV-Vis. Rapid hydrolysis is seen followed by degradation of *p*-nitrocresol.



Time-lapsed analysis of the reaction mixture by HPLC shows initial formation of *p*-nitrocresol and fenitrooxon. In subsequent stage, most of *p*-nitrocresol is degraded.


TAML-activated peroxide decomposition of Fenitrothion



Fenitrothion and Fenitrooxon Degradation - pH Dependence


Initial rate measurements following *p*-nitroresol formation (395 nm)

TAML/H₂O₂ mediated
Fenitrothion degradation



TAML®: Fenitrothion: peroxide (1: 25:
50,000) in phosphate buffer (0.1M)

Peroxide assisted
Fenitrooxon degradation




Fenitrooxon: peroxide (1:2000)
in phosphate buffer (0.1M)


p-Nitroresol Degradation – pH dependence

Optimization of Reaction Conditions

Initial rate measurements




Kinetics of oxidative degradation



At higher pH, the reaction rate increases, but catalyst gets inactivated faster

Optimum pH range 9.5-10.0

Summary of Fenitrothion degradation Study




Optimal reaction conditions for Total degradation of fenitrothion

pH 9.5-10.0, phosphate buffer (0.1 M), 25°C


TAML[®]: Fenitrothion: Peroxide 1 : 25 : 50,000

Total Degradation of Fenitrothion



Fenitrothion Degradation

Aquatic Toxicity



Vibrio fischeri

Dafnia Magna

Fenitrothion (99%)

2.33

14.1

TAML catalyst (FeBF_2)

58.00

NA

Reaction mixture
(pH 10, quenched with *catalase*)

57.25

>530

Reduction in toxicity


25-fold

>38-fold

MicroTox
 EC_{50} (15 min.)
Mg/L

D. Magna
 EC_{50}
Mg/L

Reaction of Dialkyl sulfides with TAML/peroxide



TAML:substrate = 1:1,000; pH 8; Phosphate buffer, 25°C

Conclusions

TAML[®]-peroxide technology:

- Effectively deactivate bacterial spores, the toughest of all microorganisms, in aqueous solution achieving 99.99999% (7-log) of spore destruction
- Rapidly detoxify organo-phosphorus triesters, followed by the deep oxidation of hydrolysates
- Selectively oxidize dialkyl sulfides to less toxic sulfoxide
- Promises an environmentally friendlier superior technology for destruction of all chemical-biological warfare agents

New Decon System Features

- **Catalytic** – Requires very low catalyst and low peroxide concentration
- **Designed to be Non-toxic** – No toxic elements or functionality
- **Aqueous based** – Compatible with wide variety of surfaces and technologies; can be used on sensitive equipment
- **Broad-spectrum activity** – Detoxify and degrade large-range of chemicals and inactivate bacterial spores
- **Performance previously unavailable** – Truly biomimetic with deep oxidation capability (leaves no toxic biproducts)
- **Robust system** – Stable and functional over wide range of pH
- **Rapid acting and safe** - for people and environment
- **Easy to use** – Used at ambient conditions, offers a practical approach

Acknowledgements

Anindya Ghosh

Dr. Peter Berget

Dr. Edwin Minkley

NSF


DURIP





Nucleophile assisted Hydrolytic Detoxification of Chemical Warfare Agents

Peroxy Anion (OOH⁻)




The rate of nucleophile aided hydrolysis of esters is increased by cationic micelles (e.g. ⁻OOH/CTABr).

Wagner and Yang, 2002.

Ind. Eng. Chem. Res., 41(8), 1925-1928



Fe-TAML peroxide oxidant system mimics Cytochrome 450




TAML-activated peroxide treatment of fenitrothion possibly results in a common 3-membered ring intermediate formation leading to fenitrooxon and p -nitrocresol

TAML/H₂O₂ Degradation of Organophosphorus Triesters


A Versatile and Robust Process



Fenitrothion



Chlorpyrifos



Quinalphos



Diazinon



Catalysis of Phosphate Triester Hydrolysis by Cationic Micelles


- Nucleophile (such as peroxide anion) aided hydrolysis is the most preferred reaction to detoxify phosphorus esters.
- The rate of nucleophile aided hydrolysis of esters is increased by cationic micelles (e.g. $^-\text{OOH}/\text{CTABr}$).^{1,2}
- CTABr has significantly enhanced hydrolytic rate of phosphorus esters, (depending on substrate, 20-300 fold enhancement) with hypochlorite.¹
- Aqueous cationic micelles accelerate spontaneous hydrolysis of dinitrophenyl phosphate and acyl phosphate dianions, with an extensive P-O bond cleavage in the transition state.³

1. Dubey, Gupta et al., *Langmuir*, **2002**, 18, 10489-10492



2. Couderc and Toullec, *Langmuir*, **2001**, 17, 3819-3828.

3. Brinchi, profio et al., *Langmuir*, **2000**, 16, 10101-10105

Bacterial Endospore Spore Cortex



- Loosely cross-linked peptidoglycan composed of *N*-acetyl glucosamine and *N*-acetylmuramic acid with short peptide side-chains
- Maintains spore dormancy and heat resistance; hydrolyzes during germination
- An overall negative charge — from the phosphate backbone of teichoic acid (20-40% of dry weight of cortex)



Teichoic Acid